

Planterboxdirect.com- Planter Box Assembly Instructions

1. Locate all parts. 2- side panels, 2- end panels, 4- outside corners, 24- color match screws.
2. Locate the HEM section of the panels and outside corners (top)
3. With HEM section UP, align top piloted hole on (1) outside corner to (1) end panel, using a ¼" bit (not included) screw in until snug
4. Align center piloted hole, using a ¼" bit (not included) screw in until snug
5. Align bottom piloted hole, using a ¼" bit (not included) screw in until snug
6. Repeat steps 3, 4 & 5 until each end panel (2) has 2 outside corners screwed on to each
7. Locate 1 side panel, with the HEM up align the top piloted hole on (1) corner to the side panel, using a ¼" bit (not included) screw in until snug
8. Align center piloted hole, using a ¼" bit (not included) screw in until snug
9. Align bottom piloted hole, using a ¼" bit (not included) screw in until snug
10. Repeat steps 7, 8 & 9 until each side panel (2) have been screwed onto the outside corners.
11. Your planter box is now complete. Enjoy!



Required tools (not included) (Drill, ¼" driver or Ratchet with ¼" drive)

